


Microfiche layout



1. Read from left to right

2. Title of microfiche (appears on each coordinate)


E 16	Product/assembly/test step	
	Vehicle/engine	

Coordinate

3. Limits of section



Beginning



Mid-section



End



One-page section

4. Purely vehicle-specific passages in the text are marked with a vertical bar.

5. Reference to relevant working steps in the test specifications, e.g. coordinate C6.

C 6

A 1

Trouble-Shooting Plan



1. Test specifications

1.1 Electric fuel pump

Test step

Test specifications

Fuel delivery:

min. 850 cm³/30 s


C11

A2

Test specifications

Volvo 260 ..





p = Control pressure (gauge pressure)

t = Ambient temperature

1.2 Control pressure "cold"

D4

For testing, connect vacuum pump to intake-manifold-pressure connection of warm-up regulator.

Setting value: 510...550 mbar
(385...415 mmHg)

Part no. of warm-up regulator: 0 438 140 005
0 438 140 018

(Versions for intake-manifold-pressure-controlled full-load enrichment).

A3

Test specifications

Volvo 260 ..



1.3 Control pressure "warm"

(Versions for intake-manifold-pressure-controlled full-load enrichment).

- Test at atmospheric pressure (without vacuum):

Part no. of warm-up regulator

0 438 140 005

2.7 ...3.1 bar
(2.8...3.2 kgf/cm²)

0 438 140 018

3.0 ...3.4 bar
(3.1...3.5 kgf/cm²)

- For testing, connect vacuum pump to intake-manifold-pressure connection of warm-up regulator.

Setting value:

510...550 mbar (383...415 mmHg)

Part no. of warm-up regulator

0 438 140 005

3.4...3.8 bar
(3.5...3.9 kgf/cm²)

0 438 140 018

3.4...3.8 bar
(3.5...3.9 kgf/cm²)

- Leak test on full-load diaphragm
Max. pressure drop
as of setting value: 100 mbar (75 mmHg)/15 sec.

+ Pressures in the test specification table are given in bar (gauge pressure) and/or in kgf/cm² (gauge pressure)



Test stepTest specifications ***D 16**1.4 Primary pressure

(Fuel distributor: 0 438 100 006)

Checking value: 4.5...5,2 bar (4.6...5.3 kgf/cm²)
Setting value: 4.7...4.9 bar (4.8...5.0 kgf/cm²)

E11.5 Leak test

(Fuel accumulator: 0 438 170 007)

Minimum pressure
after 10 minutes: 2.0 bar (2.1 kgf/cm²)
after 20 minutes: 1.7 bar (1.8 kgf/cm²)

E181.6 Injection valves

(0 437 502 005)

Opening pressure: 2.5...3.6 bar
(2.6...3.7 kgf/cm²)

1.7 Fuel distributor**F2**

0 438 100 006

Comparative measurement of fuel delivery from outlets:	Setting point	Max. allowable delivery
Idle	6.0 cm ³ /min	6.8 cm ³ /min
Part load	40.0 cm ³ /min	44.0 cm ³ /min
Full load	145.0 cm ³ /min	160.0 cm ³ /min

Note: The value of 145 cm³/min must be reached at least at all outlets with full deflection of air-flow sensor plate.

* Pressures in the test-specification table are given in bar (gauge pressure) and in kgf/cm² (gauge pressure).

A5Test specifications

Volvo 260 ..



1.3 Idle adjustment:

Idle speed

Automatic transmission:

1000 min⁻¹

Manually-shifted transmission:

900 min⁻¹

CO concentration (% by vol.)

Checking value:

1.0...3.0%

Setting value:


2.0%

Note:

Re-adjust CO according to "setting value".

Engines whose CO concentration is within the "checking value" tolerance need not be re-adjusted if otherwise running smoothly.






2. Electrical circuit diagram (safety circuit)

2.1 Circuit diagram:

- 1 = Start valve
- 2 = Thermo-time switch
- 3 = Electric fuel pump
- 4 = Warm-up regulator
- 5 = Auxiliary-air device
- 6 = Air-flow sensor contact
- 7 = Relay 1
- 8 = Relay 2






438/0611

2.2 Bridging the safety circuit

In order to bridge the safety circuit it is sufficient to switch on the ignition and to remove the double connector from the socket on the air-flow sensor (arrow).

The components electric fuel pump, warm-up regulator and auxiliary-air device are triggered via relays I and II whereby the ignition must be on and the contact in the air-flow sensor open (air-flow sensor plate raised).



3. Diagram of fuel lines

1 = Fuel tank
 2 = Electric fuel pump
 3 = Fuel accumulator

4 = Fuel filter
 5 = Mixture-control unit
 5.1 = Fuel distributor

5.2 = Air-flow sensor
 6 = Warm-up regulator
 7 = Injection valve
 8 = Start valve

A9

Diagram of fuel lines
 Volvo 260 ..



A10

Diagram of fuel lines
 Volvo 260 ..



4. General information

4.1 Introduction:

This repair manual refers to the Volvo vehicle model 260... with engine B27E of model years 1975 - 1977 (K-Jetronic with updraft air-flow sensor) and gives a concise description of the testing and adjustment operations to be performed on the vehicle on the K-Jetronic.

All the system components are dealt with in separate working steps with the corresponding test specifications.

In addition to this repair manual the appropriate testing and repair manuals will, of course, be issued for every other vehicle type equipped with the K-Jetronic.

The K-Jetronic differs from other known fuel-injection systems in terms of both construction and operation. In order to be able to carry out the testing procedures described in this manual - and therefore to be able to assess the components - the K-Jetronic and its operation should be clearly understood. The essential points of the operation and construction of the K-Jetronic are described in Technical Instruction VDT-U 3/1 En.



When trouble-shooting the K-Jetronic, it is assumed that the ignition is in order and that the engine is in proper mechanical condition.

The individual test steps of this repair manual are detailed and self-contained. This permits direct trouble-shooting without having to go through the entire test program for each fault.

The trouble-shooting chart on Coordinates B 1 - B 4 is intended to make it easier to decide which test steps have to be carried out for certain faults.

According to the symptom stated by the customer or which you yourself have determined, select the possible cause in the trouble-shooting chart. The coordinate at the end of the cause column refers to the appropriate test step with the associated test specification.

Important note:

If any fuel connections are loosened, parts removed, also on the vacuum system, always use new seals when re-connecting or re-installing.

Ensure utmost cleanliness when working on the K-Jetronic. Fuel connections must be cleaned thoroughly on the outside before opening.



4.2 Design of the K-Jetronic:

The entire system of the K-Jetronic in the Volvo 260... with engine B 27 E (model year 75-77) corresponds to the basic design as described in Technical Instruction VDT-U 3/1. The air-flow sensor in this model is of the updraft type. The same engine type as of the 1978 model has been provided with a completely changed intake system with downdraft air-flow sensor.

The warm-up regulator is a version for manifold-pressure-controlled full-load enrichment.

4.3 Electrical safety circuit:

The electric fuel pump, warm-up regulator and auxiliary-air device are controlled by 2 relays whereby the control relay switches as a function of the safety contact in the air-flow sensor (sensor-plate stop).

The start valve is, as usual, energized by the thermo-time switch during cold starting depending on the temperature of the engine.



5. Test equipment and tools

- Pressure tester KDJE-P 100 (previously KDEP 1034)
For testing all fuel pressures and testing for leaks.
- Connecting-parts set KDJE-P 100/12

For connecting pressure tester KDJE-P 100 (previously KDEP 1034) to the control-pressure port of the fuel distributor.

- Guide ring KDEP 1040/10 (Ø 80 mm)
For centering the air-flow sensor plate in the air-flow sensor.
- Tester for delivered quantity comparison KDJE-P 200 (previously KDJE 7451)
For comparing the fuel delivered from the individual fuel-distributor outlets.
- Electric connecting cable (test lead)
KDJE 7450/70 for the direct connection of components to be tested, e.g. cold-start valve.



- Graduate (commercially available, capacity approx. 1.5 l)

For measuring the delivery of the electric fuel pump.

- Valve tester KDJE-P 400 (previously KDJE 7452).

For testing the injection valves.

Test media: Calibrating fluid (Shell K 30, Esso-Varsol, Shell Mineral Spirits 135)

or

Bosch, Part Designation 14 942-CH

Previously, Part No. 5 973 340 650

The Bosch calibrating fluid can be obtained in 5 l metal cans from the following supplier:

Firma

Oskar Gnamm GmbH & Co.

D-7531 Kämpfelbach-Bilfingen

Caution:

For safety reasons, never use normal gasoline or similar easily inflammable and combustible liquids.

Even with calibrating fluid, be sure to observe the local official regulations.

- Assembly tool KDEP 1039

For mounting polyamide hose line on delivery-end connection of electric fuel pump.




- Tachometer (commercially available)

For idle-speed adjustment

- CO meter (commercially available)

For idle-speed CO adjustment.






- 1 = Pressed in and brazed
- 2 = Hexagon AF 3
- 3 = Bore 3.2 mm dia.

A special adjusting wrench, min. 280 mm long, is required for setting the idle-mixture-adjusting screw (CO adjustment). This wrench is not included in the Bosch service tools program. It can easily be user-fabricated according to the above sketch.

Note: For the hexagon key AF 3 it is advisable to use a commercially available hexagon-socket-screw key which is shortened to the appropriate length.




6. Installation position of individual components

6.1 Arrangement of components on engine (Air filter removed)

- 1 = Safety circuit relay
- 2 = Fuel filter
- 3 = Start valve
- 4 = Auxiliary-air device
- 5 = Warm-up regulator
- 6 = Mixture-control unit (hidden by intake manifold)
- 7 = Injection valves
- 8 = Thermo-time switch





- 1 = Fuel accumulator
- 2 = Electric fuel pump
- 3 = Fuel tank
- 4 = Fastening nuts of bracket
- 5 = Delivery fitting with integrated non-return valve

6.2 Fuel-supply components:

The electric fuel pump and fuel accumulator are located on a common bracket which is mounted under the luggage compartment floor, on the left-hand side as viewed in the forward direction of travel, next to the fuel tank.



7. Trouble-shooting chart

When trouble-shooting the K-Jetronic, it is assumed that the ignition is in order and that the engine is in proper mechanical condition.

The individual test steps of this repair manual are detailed and self-contained. This permits pin-pointed trouble-shooting without having to go through the entire test program for each fault.

The trouble-shooting chart on Coordinates B 2 - B 5 is intended to make it easier to decide which test steps have to be performed for which faults.

Select the possible cause in the trouble-shooting chart in accordance with the complaint stated by the customer or which you yourself have determined. The Coordinate at the end of the cause column refers to the appropriate test step with the corresponding test specification.

B 1

Trouble-shooting chart

Volvo 260 ..



7. Trouble-shooting chart (see also Coordinates (B 3/B 4))

Customer complaint (fault symptom)

1. Engine does not start, or starts poorly, in cold condition
2. Engine does not start, or starts poorly, in warm condition*
3. Irregular idling during the warm-up phase (shakes)
4. Irregular idling with warm engine (shakes)
5. Engine does not draw gas, burbles
6. Engine misfires when operating on the road, high load
7. Insufficient power

*Note:

If, in the case of Symptom 2, after checking and repairing all the fault causes listed below, the hot-start characteristic is still unsatisfactory this can be improved by fitting an impulse relay. The fitting of this relay is described in Coordinates L 4.

							Cause	Coordinates
	●	●	●	●		●	Vacuum system leaking	B 6
●	●		●	●	●	●	Air-flow sensor lever and/or control plunger not moving smoothly	B 8
	●						Position of the air-flow sensor plate incorrect	C 4
●		●					Auxiliary-air device does not open	C 9.
●	●				●		Electric fuel pump not operating	C 11
●							Cold-start system defective	C 16
		●	●				Cold-start valve leaking	C 19
				●			Excessive fuel delivery for control-pressure circuit	C 21
●		●					"Cold" control pressure outside tolerance	D 4
	●		●	●	●	●	"Warm" control pressure too high (after warm-up)	D 10
			●	●		●	"Warm" control pressure too low (after warm-up)	D 10
					●	●	Primary (system) pressure outside tolerance	D 16
	●						Overall fuel system leaking	E 1
●	●	●	●		●		Injection valves leaking, opening pressure too low	E 19
●	●	●	●			●	Unequal fuel delivery (imbalance of fuel delivery)	F 3
●	●	●	●	●			Basic idle adjustment incorrect	G 5
						●	Throttle plate does not open completely	---

B2

Trouble-shooting chart

Volvo 260 ..



B3


Trouble-shooting chart

Volvo 260 ..



8. Engine runs on after being switched off ("diesels")						
9. Fuel consumption too high						
10. Flat spot during acceleration						
11. CO concentration during idling too high						
12. CO concentration during idling too low						
13. Idle-speed cannot be adjusted (too high)						
14. Engine starts but then immediately stops						
						Cause
		●		●		Vacuum system leaking
●		●	●	●		Air-flow sensor lever and/or control plunger not moving smoothly
●						Position of the air-flow sensor plate incorrect
					●	Auxiliary-air device does not close
					●	Electric fuel pump not operating
●	●		●			Cold-start valve leaking
		●			●	Excessive fuel delivery for control-pressure circuit
		●			●	"Warm" control pressure too high (after warm-up)
	●	●	●		●	"Warm" control pressure too low (after warm-up)
		●			●	Primary (system) pressure outside tolerance
●						Injection valves leaking, opening pressure too low
		●				Unequal fuel delivery (imbalance of fuel delivery)
●	●	●	●	●		Basic idle adjustment incorrect





438 / 1098

Test steps

8. Testing the air-intake system for leaks

The picture shows some typical points at which leaks can occur (arrows). Only 2 intake ports and 2 injection valves can be seen in the section drawing.

All six connections must be tested.

Not visible in the picture, but also to be tested: all hose connections on the intake system, e.g. on the auxiliary-air device, start valve distribution pipe and vacuum control port of warm-up regulator.

Check by performing a visual inspection or, in cases of doubt, as follows: Disconnect the hose from the outlet of the auxiliary-air device and blow air through this hose into the intake system using a compressed-air gun. The throttle valve is to be fully open. Brush connection points with soapy water, or spray with leak detector (e.g. Gupoflex).

Under no circumstances may combustible liquids be used when testing for leaks.

The formation of bubbles or foam indicates a leak.

If a leak has been eliminated, it is necessary finally to adjust the idle speed with the engine at normal operating temperature: Idle-speed adjustment is described on Coordinates G 5.

B6

Leak test on fuel system

Volvo 260 ..



B7

Leak test on fuel system

Volvo 260 ..



9. Check that the control lever in the air-flow sensor and the control plunger in the fuel distributor move freely.

9.1 Preparations:

- Engine temperature not below + 20°C.
- Remove rubber connecting dome between air-flow sensor and throttle-valve assembly (loosen two clamping bands) so that air-flow sensor plate becomes accessible.

The air-flow sensor (mixture-control unit) is located under the round intake housing, in the region between the six intake ports.


The connecting dome and then the sensor plate are more easily accessible from the flywheel end (windshield wall).

- Switch on the electric fuel pump for approx. 10 seconds by bridging the safety circuit. Control pressure is thus applied to the control plunger in the fuel distributor.

C A U T I O N!

During testing, with the electric fuel pump operating, never deflect (raise) the air-flow sensor plate since fuel will be injected through the injection valves. When the engine is subsequently started this may lead to serious engine damage.






438/0560

9.2 Check that the control lever moves freely:

Raise the air-flow sensor plate by hand and release. The sensor plate snaps back into the zero position and bounces up about twice from the spring-loaded stop.

If the control lever does not move freely, first release all 6 fastening screws holding the air-flow sensor to determine whether housing deformation is the cause of the problem. Owing to the poor accessibility of the fastening screws it is advisable to use a jointed wrench.






438/0560

If the problem is solved by loosening the fastening screws, the seal between the air-flow sensor and the bracket must be changed (Volvo service part). To do this, slightly raise the loosened mixture-control unit (possible without removing the air-intake housing).

Uniformly tighten the fastening screws cross-wise.

If the housing is not deformed, remove the mixture-control unit and repair or replace the air-flow sensor. It is advisable beforehand to perform the following test on the control plunger to prevent having to remove the mixture-control unit more than once.






9.3 Check that the control plunger moves freely.


Raise the air-flow sensor plate by hand (updraft). The same resistance must be felt over the entire movement.

Move the sensor plate rapidly back to a position just in front of the zero stop.

The control plunger follows only sluggishly, but must make noticeable contact with the sensor plate lever. If this condition is fulfilled, the control plunger can be considered to move freely.

If the control plunger does not move freely, remove the fuel distributor from the air-flow sensor.
Note the following information:






It is only possible to remove the fuel distributor after having removed the complete air-intake housing and the complete mixture-control unit.

Removal:

Unscrew the fuel connections identified by arrows:
Fuel distributor inlet on fuel filter outlet, return line on common connector right of filter, inlet line on warm-up regulator.

Remove injection valves. To do this, press spring clamps upward (injection lines can remain connected).




Remove auxiliary-air distribution pipe (with start valve) on intake manifold.

Remove all hose lines on air-intake housing.

B13

Air-flow sensor/fuel distributor
Volvo 260 ..





Unhook throttle cable on air-intake housing and on deflector roller (top arrows).

Remove plug-in connection for electrical safety circuit on air-flow sensor.

Unscrew the 4 fastening screws of the air-intake housing (flange of intake ports, 2 fastening screws on each side) (bottom arrows).


Lift off the complete air-intake housing. Do not damage the thermo-time switch in the thermostat housing.

B14

Air-flow sensor/fuel distributor

Volvo 260 ..






Unscrew both front fastening screws of the mixture-control unit bracket (shown in the picture with the air-intake housing installed).

B 15

Air-flow sensor/fuel distributor
Volvo 260 ..





Unscrew both rear fastening screws of mixture-control unit bracket and take bracket downward out of air-intake housing with mixture-control unit and connected lines.

B 16

Air-flow sensor/fuel distributor
Volvo 260 ..



Important!

Note the following when installing fuel components and fuel lines:

Always ensure utmost cleanliness when loosening or tightening the fuel connections. No dirt must enter the fuel system.


When loosening or tightening the fuel connections, apply counter-force at the fixed hexagon of the component.

Clean the fuel distributor thoroughly in the region of the fuel connections. Screw off all connections.

B17

Air-flow sensor/fuel distributor
Volvo 260 ..






Screw out three fastening screws and remove the fuel distributor from the air-flow sensor.


Remove the plunger. Under certain conditions, in order to do this it may be necessary to blow compressed air briefly against the plunger through the control-pressure connection hole. Hold the plunger with your hand while doing this. Clean the plunger thoroughly with benzine. If the plunger still does not move freely, replace the fuel distributor





9.4 Fitting the fuel distributor

When fitting the fuel distributor, use a new seal ring between fuel distributor and air-flow sensor. Observe the rightening torque 3.2...3.8 Nm (0.32.. 0.38 kgfm).



438/1103

9.5 Installing the mixture-control unit and air-intake housing:


Connect all fuel lines to the fuel distributor; use new seal rings for inlet-union screws.

Insert complete mixture-control unit with bracket from below into air-intake unit and secure with 4 fastening screws.

B20

Air-flow sensor/fuel distributor
Volvo 260 ..






Before installing the air-intake housing, always renew the seal rings in the intake bores of the cylinder heads (arrows) (Volvo service parts).

B21

Air-flow sensor/fuel distributor
Volvo 260 ..






Carefully position the air-intake housing and tighten with four fastening screws (bottom arrows, two screws each side).

Connect the throttle cable and hook into deflector roller (top arrows).

Adjust the throttle cable so that the throttle valve and deflector roller are up against the idle stop free of tension.




Connect fuel lines for fuel distributor inlet, common connector return, warm-up regulator inlet (arrows), using new seal rings for inlet-union screws.

Remount auxiliary-air distribution pipe (with start valve) and all hose lines on air-intake system.

B23

Air-flow sensor/fuel distributor
Volvo 260 ..





438/1106

9.6 Matching the fuel distributor to the air-flow sensor for initial starting:


Matching is performed by appropriate setting of the idle-mixture-adjusting screw in the air-flow sensor. During operation, the inlet bore to the idle-mixture-adjusting screw is sealed off by a plug which is inserted through a corresponding hole in the air-intake housing (arrow b). Remove the plug and insert special adjusting wrench through both holes into the idle-mixture-adjusting screw.

(Arrow a shows the engine-speed bypass screw for the idle adjustment which must be performed at the end).

C1

Air-flow sensor/fuel distributor
Volvo 260 ..





438 / 1096

- 1 = Pressed in and brazed
- 2 = Hexagon AF 3
- 3 = Bore 3.2 mm dia.

A special adjusting wrench, min. 280 mm long, is required for setting the idle-mixture-adjusting screw (CO adjustment). This wrench is not included in the Bosch service tools program. It can easily be user-fabricated according to the above sketch.

Note: For the hexagon key AF 3 it is advisable to use a commercially available hexagon-socket-screw key which is shortened to the appropriate length.

Procedure for adjusting:

Unscrew one injection line from the fuel distributor.

Switch on the electric fuel pump by bridging the safety circuit.

C A U T I O N !

During testing, with the electric fuel pump operating, never deflect (raise) the air-flow sensor plate since fuel will be injected through the injection valves. When the engine is subsequently started, this may lead to serious engine damage.

Screw in the idle-mixture-adjusting screw slowly and without any great pressure on the adjusting wrench until fuel is just pumped from the open outlet of the fuel distributor. Then back off the adjusting screw by 1/2 turn .

Reconnect the fuel line to the fuel distributor, start the engine and warm up.

The final matching of air-flow sensor and fuel distributor is performed finally by means of the idle adjustment with the engine at normal operating temperature.

The idle adjustment is described on Coordinates G5.



10. Checking and adjusting the position of the air-flow sensor plate

10.1 Preparations

- Engine temperature is not important.
- Remove rubber connecting dome between air-flow sensor and throttle-valve assembly (loosen two clamping bands) so that air-flow sensor plate becomes accessible.

The air-flow sensor (mixture-control unit) is under the round air-intake housing, in the region between the six intake ports.


The connecting dome and then the air-flow sensor plate are more easily accessible from the flywheel end (windshield wall).

- Switch on the electric fuel pump for approx. 10 seconds by bridging the safety circuit. Control pressure is thus applied to the control plunger in the fuel distributor.

C A U T I O N !

During testing, with the electric fuel pump operating, never deflect (raise) the air-flow sensor plate since fuel will be injected through the injection valves. When the engine is subsequently started, this may lead to serious engine damage.






10.2 Centering the air-flow sensor plate

Check that the ~~sensor plate~~ is flat (not bent) and that it can move through the narrowest part of the air funnel without touching the funnel. If necessary, center it using a positioning ring KDEP 1040/10 (dia. 80 mm) as follows:

Loosen the sensor plate fastening screw. Insert the positioning ring while holding the fastening screw with pliers so that the sensor plate does not deflect downwards.



5 punch marks


Caution:

Be sure that sensor plate is mounted in correct position!
Its upper side is identified by five punch marks (in a row). The sharp edge (arrow) is at the bottom.

C6

Checking/adjusting air-flow sensor plate
Volvo 260 ..






With the positioning ring in place, tighten the fastening screw with a torque of 5.0...5.5 Nm, loosen again and tighten again with the same torque.

When tightening the screw make sure that the air-flow sensor plate is in its zero position (in the cylindrical part of the air funnel).

It must no longer be possible to turn the air-flow sensor plate by hand.



438/0374

10.3 Checking and adjusting the zero position of the sensor plate (rest position):


Switch on the electric fuel pump for approx. 10 seconds by bridging the safety circuit.

This results in application of the control pressure to the control plunger in the fuel distributor.

The upper edge of the sensor plate must be flush with the cone in the position marked with a circle in the picture. A lower position of up to maximum 0.5 mm is permissible, however the air-flow sensor plate must not project at any point on its circumference outside the cylindrical part of the air funnel.

If necessary, the position of the leaf-spring limit-stop can be corrected by adjusting the shaped spring (arrow).





- 1 = Auxiliary-air device
- 2 = Flashlight
- 3 = Mirror

11. Checking the operation of the auxiliary-air device.

The engine must be cold.

Disconnect the electric cable plugs from the auxiliary-air device and warm-up regulator.

Disconnect both air hoses from the auxiliary-air device. Since the two hose fittings on the auxiliary-air device are located exactly opposite each other, a visual check can now be made to see if the blocking plate is partially open.


It will be easier to look through the auxiliary-air device with the aid of a flashlight and a mirror, as shown in the illustration.



- If an opening is not visible with the engine cold, replace the auxiliary-air device.
- Fit the electric cable plug on the auxiliary-air device.
- By bridging the electrical safety circuit, supply power to the auxiliary-air device.
After a maximum of 10 minutes, the opening in the auxiliary-air device must be completely closed by the blocking plate.
- If the blocking plate does not close, check the power supply (open circuit, voltage drop).
Minimum voltage across the connector 11.5 V with the engine stopped.
- If these points are O.K., check the heating coil of the auxiliary-air device for an open circuit using an ohmmeter.
- Replace the auxiliary-air device if defective.

When the auxiliary-air device has been replaced, re-adjust the idle speed with the engine at normal operating temperature. Idle adjustment is described on Coordinates G5.






12. Checking the operation of the electric fuel pump

12.1 Requirement:

Conclusive information on the operation of the electric fuel pump can only be given by a measurement of fuel delivery under pressure, i.e. under primary pressure. This measurement must therefore be made at the return line leading to the fuel tank, after the return lines from primary-pressure regulator and warm-up regulator have come together (arrow).





The measuring point is the connector in the common return line right of the fuel filter.

Remove return line from the connector (arrow) and, instead, connect the test hose with an appropriate union piece.



12.3 Testing

Remove the plugs from the warm-up regulator and auxiliary-air device.

Switch on the electric fuel pump for precisely 30 seconds by bridging the safety circuit and measure the delivery in a graduate.

C A U T I O N !

Never depress (deflect) the air-flow sensor plate with the electric fuel pump operating since otherwise fuel will be injected. Subsequent operating of the starting motor may lead to serious damage.

12.4 Test specification

Fuel delivery: min. 850 cm³/30 seconds


12.5 Possible causes of insufficient fuel delivery:

- Power supply to the electric fuel pump defective, voltage drop.
Necessary minimum voltage at terminal = 11.5 V
- Fuel filter very dirty.

If the above-mentioned points are O.K., the cause lies with the electric fuel pump itself.

Replace the electric fuel pump.





438/1084

1 = Fuel accumulator
2 = Electric fuel pump
3 = Fuel tank

4 = Fastening nuts of
bracket
5 = Delivery fitting with in-
tegrated non-return valve

12.6 Removing and installing the electric fuel pump:

Pinch off intake hose before loosening (e.g. using hose clammer W 157 from Matra Co.) in order to prevent fuel from escaping.

Remove complete bracket with electric fuel pump and fuel accumulator.

Unscrew delivery line from fuel accumulator and remove electric fuel pump from bracket.



Note: Changing the electric fuel pump requires a new delivery line to the fuel accumulator. This calls for a new 45 mm long piece of polyamide line, 8 mm inside diameter, for pressures of at least 25 bar.

Using a soldering iron, cut open and remove the old line in the region of the delivery fitting (non-return valve) and of the screw nipple.

Caution: Never use an open flame for warming the line.
Danger of fire!

Likewise, do not cut the line open with a knife since this will damage the toothed section on the fitting.

Insert new hose line into assembly tool KDEP 1039 so that it projects by the amount of the length of the nipple. Clamp the assembly tool in a vice and hit the screw nipple cold into the line using a clean plastic mallet.

Clamp the other end of the delivery line in the same manner in the assembly tool and press cold onto the delivery fitting of the electric fuel pump. Hold the electric fuel pump tight when doing this - do not clamp in vice.

Important: Do not warm the line before pressing on since it will undergo permanent expansion, which will subsequently lead to leaks.

Reinstall the electric fuel pump. Remove hose clammer from intake hose and finally check all connections for leaks with the electric fuel pump operating.



13. Testing the cold-starting system (thermo-time switch, start valve)

13.1 Thermo-time switch

Remove the thermo-time switch for testing.


It is screwed into the thermostat housing in the region below the deflector roller of the throttle cable.

Caution!

If possible, remove only when the engine is cold since a small amount of coolant will escape. The amount of coolant escaping would be considerably greater if the engine were hot.

Catch escaping coolant in a container.





438/0412

The thermo-time switch used in the Volvo (not a Bosch product) has a switching temperature of 35°C and a switching time at -20°C of 7.5 seconds. Both values are marked on the hexagonal section of the thermo-time switch.

The removed thermo-time switch is tested using an ohmmeter in accordance with the values given below.

The temperatures for the thermo-time switch can easily be obtained with water. Cooling takes place in a freezer chest.

Resistance measurement (Ω) between


At a temperature below $^{\circ}\text{C}$ above $^{\circ}\text{C}$		Term. "G" and "ground" (housing)	Term "W" and "ground" (housing)	Term "G" and term. "W"
+30		25...40 Ω	0 Ω	25 ... 40 Ω
	+40	50...80 Ω	100...160 Ω	50 ... 80 Ω

1.

C18

Checking cold-start sys./t.-t. switch
Volvo 260 ..





13.2 Start valve:

Remove the start valve. Hose line remains connected. Pull off the plug and connect the start valve directly to ground and to terminal 15 (e.g. at the ignition coil) using connecting cable KDJE 7450/70.

Important note:

During this test, do not let the connecting cable touch B +. Danger of fire due to sparking!

Hold the start valve in a suitable container (e.g. the graduate).

Switch on the electric fuel pump by bridging the safety circuit.

Switch on the ignition (max. 30 seconds). The start valve must now open and spray fuel.



Switch off the ignition, remove the electric connecting cable and dry the nozzle of the start valve.

The safety circuit remains bridged so that the primary pressure is applied to the start valve.

No droplets of fuel must drip from the nozzle of the start valve during the next minute. Even if shaken and knocked, the start valve must not leak.

Then switch the electric fuel pump off again.

Replace the start valve if it does not open or if it leaks.

If a leaky start valve or a defective thermo-time switch has been replaced, it is necessary finally to adjust the idle speed with the engine at normal operating temperature.

Idle-speed adjustment is described on Coordinates G5.

C20

Checking cold-start sys./start valve

Volvo 260 ..



14. Checking the control pressures

14.1 Preliminary remarks:

The control pressures which are to be checked below are basically determined by the warm-up regulator.

If the measurement result is incorrect, however, this may also be due to faults which have nothing to do with the warm-up regulator.

These possible faults are:


- No voltage across the electrical connector or voltage too low
- Fuel return from warm-up regulator blocked or constricted.
- Fuel delivery for the control-pressure circuit too low or too high.

The testing of this control-pressure delivery is described at the beginning of the control-pressure checks as an additional test step.

Test specification: 160 ... 240 cm³/min

Reference is made to the other possible causes of trouble in the respective test step.






- 1 = Return port (M 8 x 1)
- 2 = Inlet port (M 10 x 1)
- 3 = Electric terminal
- 4 = Intake-manifold-pressure connection port (after throttle valve)

14.2 Version of warm-up regulator

The warm-up regulator is a version for intake-manifold-pressure-controlled full-load enrichment. This means that the cold and warm control pressures are additionally influenced by the intake-manifold pressure acting on the full-load diaphragm of the warm-up regulator. The intake-manifold pressure connection port (4) is located on the top of the housing cover. In the base plate there is an opening for atmospheric pressure.



4.3 Checking the fuel delivery for the control-pressure circuit:

Before testing: Make sure that the electric fuel pump is operating properly.
(Test specification: min. 930 cm³/30 s)

Unscrew the control-pressure line from the fuel distributor to the warm-up regulator on the warm-up regulator and hold in a graduate (approx. 0.5 liter capacity) for testing.

Switch on the electric fuel pump for 1 minute by bridging the safety circuit.
Measure delivery.

Test specification: 160...240 cm³/min.

If the measured value is outside tolerance, the fault is in the fuel distributor.


Replace the fuel distributor.

C24

Checking the control pressure

Volvo 260 ..





14.4 Mounting the pressure tester KDJE-P 100 (formerly KDEP 1034):


The pressure tester KDEP 1034 is equipped with a three-way valve with 2 separate valve screws. The connections of the directional-control valve are numbered (Fig. a). Since the end of 1979 the pressure tester KDJE-P 100 has been supplied. Its directional-control valve has only one valve screw (Fig. b). The connections of this directional-control valve are identified by symbols:

A = Inlet (from the fuel distributor)

B = Outlet (to the warm-up regulator)

Caution:

When the directional-control valve is not in use, always keep the valve screw(s) open in order to relieve the pressure on the seal rings.




The directional-control valve of the pressure tester is connected into the control-pressure line from the fuel distributor to the warm-up regulator.

Fit using connecting-parts set KDJE-P 100/12.

1. Screw the adapter (1) with seal onto inlet fitting A or 3 of the directional-control valve.
2. Unscrew the control-pressure line (2) on the warm-up regulator and connect with inlet-union screw M 10 x 1 and seal rings to the adapter (1).
3. Screw connecting piece (3) of connecting-parts set into inlet of warm-up regulator and, using hose line (4), connect to outlet fitting B or 1 of the directional-control valve.

Suspend the pressure gauge from the engine hood (possibly using a wire hook).






14.5 Bleeding the pressure tester

Disconnect the electric plug from the warm-up regulator. Let the pressure gauge hang down (hose fully extended).

Switch on the electric fuel pump by bridging the electrical safety circuit.

Open and close the valve screw(s) of the directional-control valve in a 10-second rhythm about 5 times.

Then hang the pressure gauge from a suitable support (e.g. from one of the struts under the engine hood). Open valve screw of directional-control valve (both screws in the case of KDEP 1034) (turning to the left).



a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

14.6 Testing the "cold" control pressure:

Warm-up regulator: 0 438 140 005 / 018


The test is performed with the engine switched off. The engine must be cold. For this purpose, the engine should have been switched off for several hours, preferably overnight.

Pull off the plug from the warm-up regulator.

Open the valve screw of the directional-control valve (both screws in the case of KDEP 1034).

Switch on the electric fuel pump by bridging the electrical safety circuit.





The control pressure is tested with simulated intake-manifold pressure, i.e. by applying vacuum to the warm-up regulator.

To do this, connect the vacuum pump to the intake-manifold-pressure connection port of the warm-up regulator on the top of the housing. The picture shows testing with the recommended Mityvac hand vacuum pump.


Setting value for testing: $\frac{510 \dots 550 \text{ mbar}}{(385 \dots 415 \text{ mmHg})}$

The "cold" control pressure is indicated on the pressure gauge of the pressure tester.

D5

Checking the control pressure
Volvo 260..





p = Control pressure (bar or kgf/cm² gauge pressure)
 t = Ambient temperature (°C)

Warm-up regulator Part No.: 0438 140 005 / 018

Calculate the nominal control pressure in accordance with the ambient temperatures in the graph.

Example: Ambient temperature = 20°C

Nominal control pressure = 1.4...1.8 bar
 gauge pressure



If the measured "cold" control pressure differs from the nominal value, this may be due to one of the following faults:


- Fuel delivery for the control-pressure circuit too low or too high. Test fuel delivery.


Test value: 160...240 cm³/min.

- Fuel return from warm-up regulator blocked or constricted (if control pressure too high).
Eliminate restriction.
- Warm-up regulator defective.
Replace warm-up regulator.

When the warm-up regulator has been replaced or a fault remedied, carry out the idle adjustment with the engine at normal operating temperature.

Idle adjustment is described on Coordinate G 5.





14.7 Testing the full-load diaphragm for leaks:

Switch off the electric fuel pump.

Connect vacuum pump to intake-manifold-pressure connection port of warm-up regulator and build up vacuum.

Setting value: 510...550 mbar (385...415 mmHg)

Test specification for air leaks:

Max. permissible pressure drop within 15 sec:

100 mbar (75 mmHg)

If pressure drop is too fast, replace warm-up regulator.

Note:

The previously described control-pressure test indicates whether the control-pressure circuit and warm-up regulator are O.K.

Incorrect control-pressure operation during vehicle operation may, however, also be due to a malfunction of the vacuum control for the warm-up regulator.


Therefore, also check the condition and routing of the vacuum hose as well as its connection to the air-intake system.

If in doubt, test the vacuum control with the engine running.

When the warm-up regulator has been replaced or a fault remedied, carry out the idle adjustment with the engine at normal operating temperature.

Idle adjustment is described on Coordinates G 5.





438/0316


a = To warm-up regulator
b = To pressure gauge
c = From fuel distributor

14.8 Testing the "warm" control pressure:

Warm-up regulator Part No.: 0438 140 005 / 018

The test is performed with the engine switched off.
The temperature of the engine is not important.

Open the valve screw of the directional-control valve
(both screws in the case of KDEP 1034).



For testing with simulated intake-manifold pressure, connect the vacuum pump to the intake-manifold-pressure connection port of the warm-up regulator (on the top of the housing near the plug housing). The picture shows testing with the recommended Mityvac hand pump.

Setting value for testing: $\frac{510...550 \text{ mbar}}{(385...415 \text{ mmHg})}$

Testing

Switch on the electric fuel pump by bridging the electrical safety circuit.

Connect the plug to the warm-up regulator.

Control pressure now rises (warm-up regulator in the process of shutting off) until the "warm" control pressure is reached.

First of all, test without application of manifold pressure, then test with simulated manifold pressure (vacuum) according to the following values:

Test step	Test specifications*
-----------	----------------------

- Test with atmospheric pressure (without vacuum):

Warm-up regulator no.

0 438 140 005	2.7...3.1 bar (2.8...3.2 kgf/cm ²)
---------------	--

0 438 140 018	3.0...3.4 bar (3.1...3.5 kgf/cm ²)
---------------	--

- For testing, connect vacuum pump to intake-manifold-pressure connection port of warm-up regulator.

Setting value:

510...550 mbar

(385...415 mmHg)

Warm-up regulator no.

0 438 140 005	3.4...3.8 bar (3.5...3.9 kgf/cm ²)
---------------	--

0 438 140 018	3.4...3.8 bar (3.5...3.9 kgf/cm ²)
---------------	--

* Pressures in the test-specification table are given in bar (gauge pressure) and in kgf/cm² (gauge pressure).



If the measured "warm" control pressure differs from the test specification, this may be due to one of the following faults:

If control pressure too high:

- Fuel delivery for the control-pressure circuit too high.

Test fuel delivery.


Test specification: 160...240 cm³/min.

- Fuel return from the warm-up regulator blocked or constricted. Eliminate constriction.
- Warm-up regulator has hydraulic defect. Replace warm-up regulator.

If control pressure too low:

- Power supply open-circuit. Eliminate open circuit. Ensure that the plug is contacting properly.
- Battery voltage too low, voltage drop. Eliminate voltage drop. Minimum voltage at connector: 11.5 V. If necessary, repeat test with engine running in order to obtain the normal generator voltage of approx. 14 V when the vehicle is in operation.
- Fuel delivery for the control-pressure circuit too low. Test fuel delivery. Test specification: 160...240 cm³/min.
- Warm-up regulator defective. Heating coil open-circuit. Hydraulic defect. Replace warm-up regulator.





14.9 Testing the full-load diaphragm for leaks:

Switch off the electric fuel pump.

Connect vacuum pump to intake-manifold-pressure connection port of warm-up regulator and build up vacuum.

Setting value: 510...550 mbar (385...415 mmHg)

Test specification for air leaks:

Max. permissible pressure drop within 15 sec:

100 mbar (75 mmHg)

If pressure drop is too fast, replace warm-up regulator.



Note:

The previously described control-pressure test indicates whether the control-pressure circuit and warm-up regulator are O.K.

Incorrect control-pressure operation during vehicle operation may, however, also be due to a malfunction of the vacuum control for the warm-up regulator.


Therefore, also check the condition and routing of the vacuum hose as well as its connection to the air-intake system.

If in doubt, test the vacuum control with the engine running.

When the warm-up regulator has been replaced or a fault remedied, carry out the idle adjustment with the engine at normal operating temperature.

Idle adjustment is described on Coordinates G 5.






15. Testing and adjusting the primary (system) pressure:

15.1 Mounting the pressure tester KDJE-P 100
(formerly KDEP 1034):

The pressure tester KDEP 1034 is equipped with a three-way valve with 2 separate valve screws. The connections of the directional-control valve are numbered (Fig. a).






Since the end of 1979 the pressure tester KDJE-P 100 has been supplied. Its directional-control valve has only one valve screw (Fig. b). The connections of this directional-control valve are identified by symbols:

- A = Inlet (from the fuel distributor)
- B = Outlet (to the warm-up regulator)

Caution:

When the directional-control valve is not in use, always keep the valve screw(s) open in order to relieve the pressure on the seal rings.




The directional-control valve of the pressure tester is connected into the control-pressure line from the fuel distributor to the warm-up regulator.
Install using connecting-parts set KDJE-P 100/12.

Screw the adapter (1) with seal ring onto the inlet fitting A or 3 of the directional-control valve.

Unscrew the control-pressure line (2) from the warm-up regulator and connect to the adapter with inlet-union screw M 10 x 1 and seal rings.

Screw the connecting piece (3) of the connecting-parts set into the warm-up connection port of the fuel distributor and connect to outlet fitting B or 1 of the directional-control valve via hose line (4).

Suspend the pressure gauge from the engine-compartment lid (possibly using a wire hook).




15.2 Bleeding the pressure tester

Disconnect the electric plug from the warm-up regulator. Let the pressure gauge hang down (hose fully extended).

Switch on the electrical fuel pump by bridging the electrical safety circuit.

Open and close the valve screw(s) of the directional-control valve in a 10-second rhythm about 5 times.

Then hang the pressure gauge from a suitable support (e.g. from one of the struts under the engine hood). Open valve screw of directional-control valve (both screws in the case of KDEP 1034) (turning to the left).



438/0317

- a = To warm-up regulator
- b = To pressure gauge
- c = From fuel distributor

15.3 Testing the primary pressure:

The test is performed with the engine switched off.
The temperature of the engine is not important.

Close the valve screw of directional-control valve KDJE-P 100. In the case of KDEP 1034, close valve screw 1, open valve screw 3.



Primary-pressure test specification:

4.5...5.2 bar (4.6...5.3 kgf/cm²) gauge pressure


Possible causes for too low a primary pressure:

- Fuel supply faulty.
(Delivery of electric fuel pump too low).
- Primary pressure set incorrectly.
A precondition for readjustment of the primary pressure is always that the fuel supply is in order.
Measure the fuel delivery
Nominal value for fuel delivery = min. 850 cm³/30 s

Possible causes for too high a primary pressure:

- A restriction in the return line leading to the fuel tank.
- Primary-pressure regulator set incorrectly.
For this reason, before readjusting to high a primary pressure, always first check the condition of the return line leading to the fuel tank.






- | | |
|------------------------------|--------------------|
| a = Primary pressure | 4 = Control spring |
| c = Fuel return | 5 = Shim(s) |
| 1 = Fuel-distributor housing | 6 = Flat seal ring |
| 2 = O-ring | 7 = Screw plug |
| 3 = Control piston | |

15.4 Adjusting the primary pressure:

Fuel distributor part number	Setting values for primary pressure (gauge pressure)
0 438 100 006	4.7...4.9 bar (4.8...5.0 kgf/cm ²)





- | | |
|------------------------------|--------------------|
| 1 = Fuel-distributor housing | 5 = Shim(s) |
| 2 = O-ring | 6 = Flat seal ring |
| 3 = Control piston | 7 = Screw plug |
| 4 = Control spring | |


Readjust the primary pressure by changing shims Item 5.

Note: 0.1 mm more of shim thickness means about 0.15 bar pressure increase and vice versa.

When installing the screw plug, always use a new seal ring - Item 6 -.

The control piston of the primary-pressure regulator must not be lost. It was matched specially to the fuel distributor housing in the manufacturing plant and therefore is the only part of the primary-pressure regulator which must not be replaced.






16. Testing the entire fuel system for leaks.

16.1 Mounting the pressure tester KDJE-P 100 (formerly KDEP 1034):

The pressure tester KDEP 1034 is equipped with a three-way valve with 2 separate valve screws. The connections of the directional-control valve are numbered (Fig. a).






Since the end of 1979 the pressure tester KDJE-P 100 has been supplied. Its directional-control valve has only one valve screw (Fig. b). The connections of this directional-control valve are identified by symbols:

- A = Inlet (from the fuel distributor)
- B = Outlet (to the warm-up regulator)

Caution:

When the directional-control valve is not in use, always keep the valve screw(s) open in order to relieve the pressure on the seal rings.



The directional-control valve of the pressure tester is connected into the control-pressure line from the fuel distributor to the warm-up regulator. Install using connecting-parts set KDJE-P 100/12.

Screw the adapter (1) with seal ring onto the inlet fitting A or 3 of the directional-control valve.

Unscrew the control-pressure line (2) from the warm-up regulator and connect to the adapter with inlet-union screw M 10 x 1 and seal rings.

Screw the connecting piece (3) of the connecting-parts set into the warm-up connection port of the fuel distributor and connect to outlet fitting B or 1 of the directional-control valve via hose line (4).


Suspend the pressure gauge from the engine-compartment lid (possibly using a wire hook).

E3

Leak test on fuel system

Volvo 260 ..






16.2 Bleeding the pressure tester

Disconnect the electric plug from the warm-up regulator. Let the pressure gauge hang down (hose fully extended). Switch on the electric fuel pump by bridging the electrical safety circuit.

Open and close the valve screw(s) of the directional-control valve in a 10-second rhythm about 5 times.

Then hang the pressure gauge from a suitable support (e.g. from one of the struts under the engine hood). Open valve screw of directional-control valve (both screws in the case of KDEP 1034) (turning to the left).



438/0316

a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

16.3 Leak test

The test is performed with the engine switched off. Make the test with a warm engine but not immediately after the engine has been operated at a high temperature.


Open the valve screw of the directional-control valve (both valves in the case of KDEP 1034).

E5

Leak test on fuel system

Volvo 260 ..





Switch on the electric fuel pump by bridging the electrical safety circuit until the warm-up regulator has ceased to operate ("warm" control pressure).

Switch the electric fuel pump off again and observe the drop in pressure on the pressure gauge.

Test specifications for leak test:

Minimum pressure after:


10 minutes: 2.0 bar (2.1 kgf/cm²) gauge pressure
 20 minutes: 1.7 bar (1.8 kgf/cm²) gauge pressure

E6

Leak test on fuel system

Volvo 260 ..





a = To warm-up regulator
 b = To pressure gauge
 c = From fuel distributor

If the pressure drops too quickly, repeat the test with the control-pressure circuit disconnected.


Position of the valve screws:

Close the valve screw of the directional-control valve KDJE-P 100.

In the case of KDEP 1034, close valve screw 1, open valve screw 2.

If the same result is found, the leak is in the primary-pressure circuit.

If the test results are correct during the second test, the leak is in the control-pressure circuit.



438/1084

1 = Fuel accumulator
2 = Electric fuel pump
3 = Fuel tank

4 = Fastening nuts of bracket
5 = Delivery fitting with
integrated non-return
valve

16.4 Possible causes of trouble in primary-pressure circuit:

- Non-return valve in tube fitting of electric fuel pump leaking.


Part no. of electric fuel pump: 0 580 254 996

Part no. of non-return valve: 1 583 386 011

Special seal ring: 1 580 203 001

The non-return valve is integrated in the tube fitting on the pump delivery side. If leaking, replace tube fitting.





438/1084

- | | |
|------------------------|---|
| 1 = Fuel accumulator | 4 = Fastening nuts of bracket |
| 2 = Electric fuel pump | 5 = Delivery fitting with integrated non-return valve |
| 3 = Fuel tank | |

In order to replace the non-return valve, remove electric fuel pump. To do this, pinch off intake hose before loosening (e.g. using hose clammer W 157 from Matra Co.) and remove complete bracket for electric fuel pump and fuel accumulator.



Unscrew delivery line on fuel accumulator and remove electric fuel pump from bracket.


Note: Changing the non-return valve requires a new delivery line to the fuel accumulator. This calls for a new 45 mm long piece of polyamide line, 8 mm inside diameter, for pressures of at least 25 bar.

Using a soldering iron, cut open and remove the old line in the region of the delivery fitting (non-return valve) and of the screw nipple.

Caution: Never use an open flame for warming the line.
Danger of fire!

Likewise, do not cut the line open with a knife since this will damage the toothed section on the fitting.





Clamp the pump in a vise by the clamping clip (never clamp by the pump housing). Remove the delivery hose from the tube fitting and screw off the fitting.

Caution: No dirt or chips must get into the inside of the pump.

Always screw in a new tube fitting with a new seal ring. Tightening torque 16...20 Nm (1.6...2.0 kgfm).

Caution: Use only the specified seal ring, since it is of special dimensions. Always observe the specified tightening torque and do not exceed, otherwise there is the danger of warping the housing and damaging the thread.




Insert new hose line into assembly tool KDEP 1039 so that it projects by the amount of the length of the nipple. Clamp the assembly tool in a vice and hit the screw nipple cold into the line using a clean plastic mallet.

Clamp the other end of the delivery line in the same manner in the assembly tool and press cold onto the delivery fitting of the electric fuel pump. Hold the electric fuel pump tight when doing this - do not clamp in vice.

Important: Do not warm the line before pressing on since it will undergo permanent expansion, which will subsequently lead to leaks.

Reinstall the electric fuel pump. Remove hose clamber from intake hose and finally check all connections for leaks with the electric fuel pump operating.





Further possible cause of leaks in the primary-pressure circuit:

- Start valve leaking.

Remove the plug from the start valve and remove the start valve. The fuel line remains connected.

Hold the start valve in a suitable vessel (e.g. a graduate).

Switch on the electric fuel pump by bridging the electrical safety circuit so that primary pressure is applied to the start valve.

Dry off the nozzle of the cold-start valve.

No drops must fall from the nozzle of the start valve within the next minute. Even when shaken and knocked, the start valve must not leak.


Switch the electric fuel pump off again.

Replace the cold-start valve if leaky.

Finally, adjust idle speed with the engine at operating temperature.

Idle-speed adjustment is described on Coordinates G 5.





- 1 = Fuel distributor
- 2 = O-ring
- 3 = Control piston
- 4 = Control spring

- 5 = Shim(s)
- 6 = Flat seal ring
- 7 = Screw plug

Further possible cause of a leak in the primary-pressure circuit.

- Control-piston seal ring (O-ring) of the primary-pressure regulator has a leak.


Replace seal ring:

Clean fuel distributor in the region of the primary-pressure regulator.

Screw out screw plug (pay attention to shims), remove control spring and control piston.

Replace seal ring (O-ring) (2) on control piston.
Install control piston and control spring.





- 1 = Fuel distributor
- 2 = O-ring
- 3 = Control piston
- 4 = Control spring

- 5 = Shim(s)
- 6 = Flat seal ring
- 7 = Screw plug

Screw in screw plug (7) with shims (5) (as found when removing) and new flat seal ring (6).

Finally, check the primary pressure and, if necessary, adjust by changing the shims (5).

Primary pressure.

Fuel distributor 0 438 100 006

Checking value: 4.5...5.2 bar (4.6...5.3 kgf/cm²)
gauge pressure

Setting value: 4.7...4.9 bar (4.8...5.0 kgf/cm²)
gauge pressure



16.5 Possible cause of trouble in control-pressure circuit:

The fuel distributor 0 438 100 006 is a version without push-up valve. Therefore, the only possible cause of a leak in the control-pressure circuit is the warm-up regulator. Therefore, replace the warm-up regulator.

When the warm-up regulator has been replaced or a fault remedied, carry out the idle adjustment with the engine at normal operating temperature.

Idle adjustment is described on Coordinates G 5.



17. Testing the injection valves.

Remove the injection valves for testing.

When loosening the fuel lines, apply counter-force at the fixed hexagon of the injection valves.

When refitting the injection valves, it is best to replace the O-rings on the valve stem (Audi/VW service part) in order to prevent leaks and thus the entry of unmetered air.

17.1 Test equipment and test media

The following testing specification refers to valve testers KDJE-P400 (previously KDEP 7452) and 0 681 200 700.

Observe the test-media specification!

Test media: Calibrating fluid (Shell K 30, Esso-Varsol, Shell Mineral Spirits 135)

or

Bosch Part No. VS 14 942-CH

Former Part No. 5 973 340 650

The calibrating fluid can be obtained in 5 l metal cans from the following supplier:
Firma


Oskar Gramm GmbH & Co

D-7531 Kämpfelbach-Bilfingen

Caution:

For safety reasons, never use normal gasoline or similar easily inflammable and combustible liquids. Even with calibrating fluid, be sure to observe the local official regulations.





17.2 Connecting the injection valve to the tester

Connect the injection valve to the valve tester using the double nipple 2 433 045 and bleed the delivery line by operating the lever several times with the union nut open. Then tighten the union nut.


17.3 Checking for dirt

Move the hand lever slowly (about 2 seconds per stroke) back and forth with the stopcock on the pressure gauge open. If the pressure does not build up to 1...1.5 bar gauge pressure, the injection valve has a bad leak (caused, for example, by dirt stuck in it).

You can try to flush the injection valve clear by moving the lever back and forth several times strongly.

If this attempt is successful, continue the test. If it is not possible to flush the valve clear, replace it.





1 = Open

2 = Closed

17.4 Testing the opening pressure


Test specifications - opening pressure:

Part number: 0 437 502 005

Opening pressure: 2,5...3,6 bar (2,6...3,7 kgf/cm²)

Pressures in the test-specification table are given in bar (gauge pressure) and in kgf/cm² (gauge pressure).





With the stopcock closed, flush the valve out and bleed it with several rapid movements of the lever. Open the stopcock and test the opening pressure by moving the lever slowly (about 2 seconds per stroke).

If the opening pressure is outside tolerance, replace the injection valve. Individual valves can also be interchanged within a set.

17.5 Leakage test

Open the stopcock, build the pressure up slowly to a value 0.5 bar under the opening pressure determined previously (but not less than 2.8 bar gauge pressure), and hold it constant at that level. No drops must now fall from the valve for the next 15 seconds.






438/0058

17.6 Chatter test, evaluation of spray

Move the lever back and forth at about 1 stroke per second. As this is done, the valve must chatter. No drops of fuel must form at the mouth of the valve. The valve must not produce a "cord spray". Formation of a single-sided, atomized spray within an overall spray angle of about 35° is permissible (see example given in illustrations).

Illustration shows good spray formation.





438/0059


Illustration shows single-sided but nevertheless good spray formation.

E23

Testing the injection valves

Volvo 260 ..






438/0060

Poor spray formation; replace injection valves.

Illustration shows drop formation.





43810061

Poor spray formation; replace injection valves.


Illustration shows "cord" spray.

F1

Testing the injection valves

Volvo 260 ..





438/0062

Poor spray formation; illustration shows "spray in strands".


Discard defective injection valves. It is possible to replace individual injection valves within a set (for one engine).

Before installing the valves, check the condition of the rubber cup seals. Cup seals must be replaced if defective, cracked or swollen (Volvo service part).

When installing, make sure that the valves are properly seated. The spring clamps must latch in. Connect the injection lines with new seal rings.

When injection valves have been replaced, then perform the idle adjustment with the engine at normal operating temperature. Idle adjustment is described on Coordinate G 5.





18. Comparative measurement of fuel delivery of fuel distributor outlets.

This test is carried out using the tester for delivered quantity comparison KDJE-P 200 (previously KDJE 7451).


18.1 Application

By means of comparative measurements, the differences in the amounts of fuel delivered from the individual outlets on the fuel distributor are determined.

The tester is designed so that the test can be made on the vehicle without having to remove the fuel distributor.

Since the test is made with the original injection valves, the operator can recognize at the same time whether delivered-quantity scatter, if it occurs, is caused by the fuel distributor or by the injection valves.





- 1 = 3-way cock
- 2 = Small rotameter tube
- 3 = Keyboard for 8-way valve
- 4 = Adjusting screw for setting up
- 5 = Spirit level
- 6 = Large rotameter tube
- 7 = Return hose
- 8 = Polyamide hose lines (test lines)

18.2 Construction

The tester is designed for use with all engines, up to 8 cylinders, equipped with K-Jetronic.

Basically, the tester consists of a steel housing containing 2 rotameter tubes with measuring ranges of 2...15 cm³ and 10...180 cm³, an 8-way valve for key operation (Item 3) and a 3-way stopcock (Item 1).


The small rotameter tube (Item 2) is used for the idle measurement while the large tube (Item 6) is used to measure the fuel delivery at part- and full-load. The particular rotameter tube to be used is connected by means of the 3-way stopcock. Using the 8-way valve, the fuel delivery of each cylinder is tested one after the other.

Attached to the tester are 8 hoses (Item 8), each terminated with an automatic connector. When the injection valves are withdrawn from their sockets on the engine they are attached to these connectors. Each automatic connector is fitted with a push valve so that no fuel can escape from connectors that are not in use (when 4- or 6-cylinder systems are tested).

The fuel is returned to the fuel tank through a hose (Item 7) about 5 m long.

The entire test is made with a closed circuit, i.e. no fuel escapes.





- 1 = Injection tubing
- 2 = Injection valves
- 3 = Automatic connectors
- 4 = Tester hoses
- 5 = Return line to fuel tank filler neck

18.3 Setting up and connecting the tester:

Set the tester up beside the engine on a solid base (e.g. on tester trolley KDJE-W 100) and align it with the built-in spirit level at the base of the tester.

Remove the injection valves for testing. Injection lines remain connected. The injection valves are plugged into corresponding holes in the cylinder heads below the intake ports and are held in position by spring clamps.

Clean injection valves with a rag and plug into the automatic connectors of the first six tester lines in the appropriate order.

Note:


Plug in injection valves firmly as far as they will go and tighten knurled nuts so that the non-return valves of the automatic connectors are opened fully. Introduce the return hose of the tester into the fuel tank filler neck.

Remove rubber connecting dome between air-flow sensor and throttle-valve assembly (loosen two clamping bands) so that air-flow sensor plate becomes accessible.

The air-flow sensor (mixture-control unit) is under the round air-intake housing, in the region between the six intake ports.

The connecting dome and then the air-flow sensor plate are more easily accessible from the flywheel end (windshield wall).





1 = White dot

2 = Measuring line

a = Idle

b = Part load/full load

18.4 Testing


The flow comparison measurement is made in the idle, part-load and full-load ranges.

The small rotameter tube is to be used for the idle measurement (white dot to the left on control knob); part-load and full-load measurements are made using the large rotameter tube (white dot to the right).

F8

Comparative measurement of fuel delivery
Volvo 260 ..





438/0325

1 = White dot

a = Idle

2 = Measuring line


b = Part load/full load

The delivered quantities indicated on the rotameter tubes are read off at the top edge of the conical float (Item 2). On testers with a ball float the uppermost point of the ball is used for reading off. With each measurement be sure to wait until the float has reached its final position. This may take 20 ... 30 seconds in the case of small deliveries.

F9

Comparative measurement of fuel delivery
Volvo 260 ..





438/0422

The exact setting and locating of the position of the air-flow sensor plate for the various load ranges is done using a screwdriver (in the case of the idle position, a small one), which is inserted to a suitable depth between the air funnel and the air-flow sensor.

F10

Comparative measurement of fuel delivery
Volvo 260 ..




Procedure:

Switch on the electric fuel pump by bridging the electrical safety circuit.

Fixed numerical values are specified in the following test section for the maximum permissible fuel delivery differences for the individual load ranges.

The "setpoint" value always pertains to the fuel-distributor outlet with the lowest fuel delivery, i.e. in each case the outlet with the lowest delivery is to be first ascertained.





Press the key for outlet 1. Pivot the air-flow sensor plate until the corresponding rotameter tube approximately indicates the "set point" value. Fix the air-flow sensor plate in this position.

Test the remaining outlets in order to determine which outlet has the lowest fuel delivery.

Press the key for this outlet again, and set the delivery precisely to the "set point" by correcting the position of the air-flow sensor plate. Then fix the air-flow sensor plate in this position again.

Press the remaining keys one after the other, and determine the maximum fuel delivery of each outlet. A deviation in fuel delivery can only be above the "set point".



18.5 Test specifications

	Set point cm ³ /min	Max. permissible fuel delivery cm ³ /min
Idle	6.0	6.8
Part load	40.0	44.0
Full load	145.0	158.0

Note: The value of 145 cm³/min must be reached at least at all outlets with full deflection of the air-flow sensor plate.

If, in testing, a too large difference is ascertained in one of the three load ranges, the test should for safety's sake be repeated.

If the result is confirmed, you should check whether the fault lies in the fuel distributor or in the injection valves.


To do this interchange the injection valves with the greatest and smallest difference.

If the result is still the same, the fault is in the fuel distributor. If the fault follows the interchanged injection valves, it lies in the injection valves.

Change defective fuel distributor and/or replace defective injection valves.

Note the following for removing and installing the fuel distributor:






18.6 Removing and installing the fuel distributor:

It is only possible to remove the fuel distributor after having removed the complete air-intake housing and the complete mixture-control unit.

Removal:


Unscrew the fuel connections identified by arrows:
Fuel distributor inlet on fuel filter outlet, return line on common connector right of filter, inlet line on warm-up regulator.

Remove injection valves. To do this, press spring clamps upward (injection lines can remain connected).



Remove auxiliary-air distribution pipe (with start valve) on intake manifold.

Remove all hose lines on air-intake housing.




Unhook throttle cable on air-intake housing and on deflector roller (top arrows).


Remove plug-in connection for electrical safety circuit on air-flow sensor.

Unscrew the 4 fastening screws of the air-intake housing (flange of intake ports, 2 fastening screws on each side) (bottom arrows).

Lift off the complete air-intake housing. Do not damage the thermo-time switch in the thermostat housing.



Unscrew both front fastening screws of the mixture-control unit bracket (shown in the picture with the air-intake housing installed).



Unscrew both rear fastening screws of mixture-control unit bracket and take bracket downward out of air-intake housing with mixture-control unit and connected lines.

F18

Comparative measurement of fuel delivery
Volvo 260 ..



Important!

Note the following when installing fuel components and fuel lines:


Always ensure utmost cleanliness when loosening or tightening the fuel connections. No dirt must enter the fuel system.

When loosening or tightening the fuel connections, apply counter-force at the fixed hexagon of the component.

Clean the fuel distributor thoroughly in the region of the fuel connections. Screw off all connections.


Unscrew the 3 fastening screws of the fuel distributor and remove fuel distributor from air-flow sensor





Fitting the fuel distributor

When fitting the fuel distributor, use a new seal ring between fuel distributor and air-flow sensor. Observe the rightening torque 3.2...3.8 Nm (0.32... 0.38 kgfm) for the fastening screws precisely.




18.7 Installing the mixture-control unit and air-intake housing:


Connect all fuel lines to the fuel distributor; use new seal rings for inlet-union screws.

Insert complete mixture-control unit with bracket from below into air-intake unit and secure with 4 fastening screws.

Mount rubber dome between air-flow sensor and throttle-valve assembly.



Before installing the air-intake housing, always renew the seal rings in the intake bores of the cylinder heads (arrows) (Volvo service parts).




Carefully position the air-intake housing and tighten with four fastening screws (bottom arrows, two screws each side).

Connect the throttle cable and hook into deflector roller (top arrows).


Adjust the throttle cable so that the throttle valve and deflector roller are up against the idle stop free of tension.





Connect fuel lines for fuel distributor inlet, common connector return, warm-up regulator inlet (arrows), using new seal rings for inlet-union screws.


Remount auxiliary-air distribution pipe (with start valve) and all hose lines on air-intake system.



18.8 Matching the fuel distributor to the air-flow sensor for initial starting:

Matching is performed by appropriate setting of the idle-mixture-adjusting screw in the air-flow sensor. During operation, the inlet bore to the idle-mixture-adjusting screw is sealed off by a plug which is inserted through a corresponding hole in the air-intake housing (arrow b). Remove the plug and insert special adjusting wrench through both holes into the idle-mixture-adjusting screw.

(Arrow a shows the engine-speed bypass screw for the idle adjustment which must be performed at the end).



- 1 = Pressed in and brazed
- 2 = Hexagon AF 3
- 3 = Bore 3.2 mm dia.

A special adjusting wrench, min. 280 mm long, is required for setting the idle-mixture-adjusting screw (CO adjustment). This wrench is not included in the Bosch service tools program. It can easily be user-fabricated according to the above sketch.

Note: For the hexagon key AF 3 it is advisable to use a commercially available hexagon-socket-screw key which is shortened to the appropriate length.

Procedure for adjusting:

Unscrew one injection line from the fuel distributor.

Switch on the electric fuel pump by bridging the safety circuit.

C A U T I O N !

During testing, with the electric fuel pump operating, never deflect (raise) the air-flow sensor plate since fuel will be injected through the injection valves. When the engine is subsequently started, this may lead to serious engine damage.

Screw in the idle-mixture-adjusting screw slowly and without any great pressure on the adjusting wrench until fuel is just pumped from the open outlet of the fuel distributor. Then back off the adjusting screw by 1/2 turn.

Reconnect fuel line to fuel distributor.

The final matching of the air-flow sensor and fuel distributor is then performed by means of the idle adjustment with the engine at normal operating temperature.

Idle adjustment is described on Coordinate G 5.



18.9 Installing the injection valves:

Before installing the injection valves, check the condition of the rubber cup seals. Cup seals must be replaced if defective, cracked or swollen (Volvo service part).

When installing, make sure that the injection valves are properly seated. The spring clamps must latch in. Connect the injection lines with new seal rings.

18.10 Final operations

Reconnect the electrical safety circuit of the K-Jetronic. Make sure this is done properly. By means of a trial run, check that all line connections are leak-tight.

Finally, test the idle adjustment, correcting if necessary (Coordinate G 5).



19. Idle-speed adjustment

19.1 Test conditions:

Warm the engine for adjusting the idle speed (oil temperature approx. 80°C).

Important note:

If the fuel-injection tubing or injection valves were loosened or removed, the engine should be warmed up under load. The low rate of fuel flow during idling is not always adequate to drive all the air out of the fuel-injection tubing.


The idle speed must not be adjusted when the engine is too hot, e.g. immediately after being raced or after a power measurement on the roller-type test stand.

In vehicles with an air-conditioner, this should be switched off to stabilize the engine speed during idle-speed adjustment.

Rotational-speed measurement with separate tester.

Check that the throttle-plate lever makes contact with idle stop. The cable should be free of tension.





- 1 = Pressed in and brazed
- 2 = Hexagon AF 3
- 3 = Bore 3.2 mm dia.

A special adjusting wrench, min. 280 mm long, is required for setting the idle-mixture-adjusting screw (CO adjustment). This wrench is not included in the Bosch service tools program. It can easily be user-fabricated according to the above sketch.

Note: For the hexagon key AF 3 it is advisable to use a commercially available hexagon-socket-screw key which is shortened to the appropriate length.

G6

Idle adjustment

Volvo 260 ..



Test specifications for idle adjustment:

Idle speed:

Automatic transmission 1000 min⁻¹

Manually-shifted transmission: 900 min⁻¹

CO concentration (% by vol.)

Checking value: 1.0...3.0 %


Setting value: 2.0 %

Note:

Re-adjust CO according to "setting value".

Engines whose CO concentration is within the "checking value" tolerance need not be re-adjusted if otherwise running smoothly.





Adjust the idle speed at the bypass screw on the bypass-air hose (arrow a).

The idle-mixture-adjusting screw (for CO adjustment) is accessible after removing the plug in the air-intake housing (arrow b). For adjusting, insert the special adjusting wrench through both holes in the air-intake housing and air-flow sensor into the idle-mixture-adjusting screw.

Turning in a clockwise direction: Enriches the mixture

Turning in a counter-clockwise direction:

Leans the mixture

Note: Idle adjustment is performed with air filter mounted; in picture air filter is removed for sake of clarity.



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

Packaging of goods under warranty

K-Jetronic (CIS)

438

VDT-I-438/101 B
10. 1976

All components or assemblies of the K-Jetronic which are dispatched under warranty must be correctly and carefully packaged so that no further damage or impairments occur during transit, since these would not be covered by warranty.

Any fuel remnants must be removed from those K-Jetronic assemblies intended for dispatch, so as to eliminate any danger of fire during transit.

The intake openings and outlets of the assemblies must be sealed off with caps or plugs. As new products were fitted, the caps or plugs from these may be used.

The plunger of the fuel distributor is to be fitted with a protective cap of adequate size, or secured to the fuel distributor.

In addition, the assemblies are packed in tightly packed, well-sealed plastic sleeves. Fuel distributors and warm-up regulators are packed individually.

If components arrive damaged due to incorrect packaging or do not comply with these instructions, they can be returned and the warranty claim rejected.

BOSCH

Geschäftsbereich KM Kundendienst, Kfz-Abteilung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50. Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

L1

Technical Bulletin

Volvo 260 ..



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

43

Continuous Injection System mixture control-unit

VDT-I-438/100 B

Ed. 2 7.1975

Translation of German
edition of 1.7.1975

The mixture control unit is still being reported as one defective unit in warranty claims. We wish to point out expressly that the mixture control unit consists of two separate products, the air-flow sensor and the fuel distributor, and that there are separate defect numbers for them in the warranty manual. Please report only the defective product.

Accessory Sets

Various fuel distributors and warm-up regulators have been supplied up to now with pressed-in plug connectors. These will no longer be supplied in future.

	no longer available	Replacement + accessory set
Fuel distributor	0 438 100 002	0 438 100 017
	0 438 100 003	0 438 100 005 + 2 437 001 001
	0 438 100 004	0 438 100 017
Warm-up regulator	0 438 140 002	0 438 140 004 + 1 437 000 000

The accessory sets contain the required number of tailpieces and seal rings.

Please note: the accessory set 2 437 001 000 is delivered included with the fuel distributor 0 438 100 017, and does not therefore need to be ordered separately.

Electric Fuel Pump

In the Technische Mitteilung VDT-BMO 114/1 B and the Service Information sheet VDT-I-740/2-1 B 1st. supplement, we announced that the non-return valve can be replaced on the electric fuel pump 0 580 254 996. We have come to the conclusion from the warranty claims that not enough use is being made of this possibility. Please bear this fact in mind and repair leaky electric fuel pumps before deciding to replace the entire assembly.

In case of inquiry, please contact your authorized representative.

ROBERT BOSCH GMBH
Geschäftsbereich KH
Kundendienst - Technik

BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

L2

Technical Bulletin

Volvo 260 ..



After-sales Service

Technical Bulletin

438

Only for use within the Bosch organization. Not to be communicated to any third party

EXCHANGEABLE NON-RETURN VALVES
in electric fuel pumps 0 580 254 ..

VDT-I-438/104 En
3.1983
(Replaces Ed. 5.1982)

Electric fuel pump	Parts set (non-return valve + seal ring)	Non-return valve	Seal
0 580 254 001	1 587 010 500	---	---
002	500	---	---
0 580 254 003	502	---	---
004	502	---	---
005	502	---	---
006	502	---	---
007	500	---	---
948	005	---	---
949	002	---	---
950	006	---	---
951	006	---	---
952	002	---	---
953	501	---	---
954	002	---	---
956	002	---	---
957	002	---	---
958	002	---	---
959	002	---	---
960	002	---	---
961	002	---	---
962	002	---	---
963	005	---	---

BOSCH

Geschäftsbereich KM-Kundendienst, Kfz-Ausüstung
© by Robert Bosch GmbH, D-70 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

L3

Technical Bulletin

Volvo 260 ..



Electric fuel pump	Parts set (non-return valve + seal ring)	Non-return valve	Seal ring
0 580 254 964	1 587 010 002	---	---
965	002	---	---
966	002	---	---
967	002	---	---
968	002	---	---
969	002	---	---
970	002	---	---
971	002	---	---
972	002	---	---
973	002	---	---
974	002	---	---
975	003 ④	---	---
976	004 ③	---	---
977	004 ③	---	---
978	1 587 410 901	---	---
979	010 004 ③	---	---
980	002	---	---
981	002	---	---
982 ①	003 ④	---	---
982 ②	1 587 410 901	---	---
984	010 004 ③	---	---
985	---	1 583 385 006	1 580 203 002
986	---	386 011	001
987	---	008	001
988	---	008	001
989	---	008	001
990	---	385 004	002
991	---	004	002
992	1 587 010 001	---	---
996	---	386 011	001
998	---	385 004	002
9 580 234 003	002	---	---
005	002	---	---

1 = up to FD 822

2 = from FD 823

3 = Parts set ..003 also possible (delivery-line connection at 90°)

4 = Parts set ..004 also possible (delivery-line connection axial)



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

HOT-STARTING PROBLEMS

438

VDT-I-438/105 En

3.1980

K-Jetronic

Replaces Ed. 2.1980

Hot-starting problems can occur in various vehicles fitted with K-Jetronic. This means that when an engine is switched off whilst still hot and then switched on again after a short period, it does not start as well as it should.

The engine, the ignition system and the K-Jetronic system in these vehicles should be carefully checked. With the K-Jetronic particular attention should be paid to the:

- complete system (in case of leaks),
- injection valves (in case of leaks),
- correct position of the air-flow sensor plate (rest position).

Instructions can be found in the vehicle-related repair manuals VDT-W-438/5..

If the engine still does not start satisfactorily when hot, even after checking, a timing relay can be fitted in K-Jetronic systems which are not equipped with a solenoid valve for reducing the control pressure as additional starting help.

Timing relay 0 340 000 003 controls the start valve during hot starts. The start valve then injects extra fuel intermittently (sometimes cutting out completely).

The timing valve is fitted according to the wiring diagram (see reverse side). The fitting of this relay will be charged for.

After fitting the timing relay starting should be carried out as follows:

Vehicles with <u>start valve in intake manifold</u>	-	with <u>open throttle valve</u> ,
Vehicles with <u>start valve in idle duct</u>	-	with <u>closed throttle valve</u> .

BOSCH


Geschäftsbereich KH Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L5

Technical Bulletin


Volvo 260 ..





K-Jetronic system with post-injection relay

- 1 = Timing relay 0 340 000 003
- 2 = Post-injection relay
- 3 = Thermo-time switch
- 4 = Start valve



K-Jetronic system without post-injection relay



After-sales Service

Motor Vehicle Service Information

Only for use within the Bosch organization. Not to be communicated to any third party.

HOT-STARTING PROBLEMS

VDT-I-Gen. 050 En

on vehicles fitted with Jetronic

9.1982

Customer complaints

If the vehicle is parked and the engine switched off after having been run at normal operating temperature, it often occurs that the engine proves difficult to start, or won't start at all, and when it does start it runs extremely roughly (only on 2 or 3 cylinders). The engine has to be accelerated a number of times before it runs smoothly.

Causes

For economic reasons ("stretching" of the mineral-oil reserves), it can happen that alcohol in varying quantities has been added to gasoline. Methanol is used for instance.

Such alcohol-added fuels, depending upon the amount of alcohol, adversely affect the hot-starting characteristics of the engine. The addition of alcohol raises the vapor pressure of the fuel and the result is that the boiling point of the alcohol-fuel mixture drops. This in turn leads to the formation of fuel-vapor locks in the fuel system when the engine has been switched off.

This means that when starting, and during the subsequent idle period, the air-fuel mixture is temporarily too lean.

Remedies

- Check the ignition and Jetronic systems, particularly for leaks.
- Changing to another brand of gasoline can sometimes cure the problem immediately.
- In many cases, fully depressing the gas pedal helps during starting, as does slightly depressing the gas pedal during the idle period until the engine runs smoothly.
- Fit the pulse relay 0 340 000 003 (refer also to VDT-I-438/105) in vehicles with K and D-Jetronic.
This step, though, will still not fully alleviate the rough running of the engine during the starting off phase

Note:

The pulse relay 0 340 000 003 is NOT to be installed in vehicles fitted with L-Jetronic.

Please direct questions and comments concerning the contents to our authorized representative in your country.

BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L7

Motor Vehicle Service Information

Volvo 260 ..



After-sales Service

Motor Vehicle Service Information

Only for use within the Bosch organization. Not to be communicated to any third party.

COLD START - WARM UP ACCELERATION PROBLEMS

VDT-I-Gen. 051 En
10.1982

in vehicles with Jetronic

Customer complaints

- Starting problems with a cold engine
- Engine bucking during warm up
- Uneven idle (speed fluctuations)
- Engine cuts out during acceleration (flat spot)
- Loss of output

Cause

When the ignition and the Jetronic have been checked and the test specifications given have been reached, a possible reason for the problems quoted could be coke residue on the intake valves.

The carbon residue thus present delays a continuous flow of fuel from the injection valve to the combustion chamber on account of its sponge effect.

As a result of this the air-fuel mixture can in some cases be so lean, that it can no longer be ignited.

Loss of output results from a reduction in the amount of cylinder filling and is caused by a very high coking.

Complex connections between qualities specific to the engine, the engine oil and fuel used, as well as relevant driving cycles (e.g. mainly short stretches) can cause such coking on the intake valves.

Remedy

Dismantle the intake valves and remove the deposits.

Please note

Various vehicle manufacturers are working at the moment on other measures, such as cleaning with additives. Results of these tests are not yet available.

BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
© by Robert Bosch GmbH D-7 Stuttgart 1 Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L8

Motor Vehicle Service Information

Volvo 260 ..



After-sales Service

Motor Vehicle Service Information

Only for use within the Bosch organization. Not to be communicated to any third party.

LIQUID PETROLEUM GAS (AUTOGAS) SYSTEMS AND
VEHICLES WITH K-JETRONIC

VDT-I-Gen. 052 En
10.1982

Fitting at a later stage

Vehicles with K or L-Jetronic are not suitable for fitting at a later stage with liquid petroleum gas (LPG) systems.

Numerous problems can occur, such as:

- Reduction of fuel flow through the injection valves due to deposits
- Stiffness or blocking of the K-Jetronic fuel distributor plunger (due to gumming or similar) in the course of time with "gas only operation."
- Increased danger of backfiring in the intake manifold (burbling) and thereby damage to the air-flow sensor.

Guarantee

Guarantee claims for failed Jetronic components from vehicles thus converted will not be accepted.

Conversion to liquid gas operation is made at the risk of the vehicle owner.

BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
© by Robert Bosch GmbH D-7 Stuttgart 1 Postfach 50 Printed in the Federal Republic of Germany
imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

L9

Motor Vehicle Service Information

Volvo 260 ..



Table of contents

<u>Section</u>	<u>Coordinates</u>
Microfiche layout	A 1
1. Test specifications.....	A 2
2. Electrical safety circuit.....	A 7
3. Diagram of fuel lines.....	A 9
4. General information.....	A 11
5. Test equipment and tools.....	A 14
6. Installation position of individual components.....	A 18
7. Trouble-shooting chart.....	B 1
Working steps	
8. Testing the vacuum system (air-intake system) of the engine for leaks.....	B 6
9. Testing the control lever in the air-flow sensor and the control plunger in the fuel distributor for ease of movement.....	B 8
10. Testing and adjusting the position of the air-flow sensor plate.....	C 4
11. Checking the operation of the auxiliary-air device.....	C 9



Table of contents (continued)

<u>Section</u>	<u>Coordinates</u>
12. Checking the operation of the electric fuel pump.....	C 11
13. Checking the cold-start system (thermo-time switch, start valve).....	C 16
14. Testing the control pressures (warm-up regulator)	C 21
14.3 Testing the fuel delivery for the control-pressure circuit.....	C 23
14.4 Mounting the pressure tester KDJE-P 100 (formerly KDEP 1034).....	D 1
15. Checking and adjusting the primary pressure.....	D 16
16. Checking the overall fuel system for leaks.....	E 1
17. Testing the injection valves.....	E 18
18. Comparison of delivered quantities.....	F 3
18.3 Setting up and connecting the tester for delivered quantity comparison KDJE-P 200 (previously KDJE 7451).....	F 6
19. Idle-speed adjustment.....	G 5



Table of contents (continued)

Section

Coordinates

Technical Bulletins.....	L 1
Service Information.....	L 7

© 1983 Robert Bosch GmbH

Automotive Equipment - After-Sales Service

Département for Technical Publications KH/VDT.

Postfach 50, D-7000 Stuttgart 1

Published by: After-Sales Service, Department for
Training and Technology (KH/VSK). Press date: 6.1983
9.1982

Please direct questions and comments concerning the
contents to our authorized representative in your
country.

This publication is only for the use of the Bosch
After-Sales Service Organization, and may not be passed
on to third parties without our consent.

Microfilmed in the Federal Republic of Germany, Micro-
photographié en République Fédérale d'Allemagne.

